



MPL-10 MICROPHONE BOOMPOLE User Manual



Introduction

Thank you for purchasing our MPL-10 Microphone Boompole, and welcome to the LyxPro™ family. This user manual offers you a brief walkthrough of the device's features and usage protocols. For additional information and technical support, please contact our helpful team at info@lyxpro.com.

Features


- Lightweight High-Grade Aluminum Construction with Padded Handlebar
- 5 Telescoping Sections for Reach Range of 2.4' (0.73m) to 9.25' (2.82m)
- Easy-Twist Section Locks Enable Quick One-Hand Range Adjustments
- Clever Hollow Core Offers Internal Wiring Options; Weighs Just 1.65 Lbs.
- 1-Year Warranty Against Manufacturing Defects & Shipping Damage

Box Contents

- 1 x Microphone Boompole
- 1 x Alternate Sizing Nut
- 1 x Owner's Manual

Parts & Controls

1. Rubber Cap
2. Microphone Screw
3. Removable Head
4. Head Screw
5. Wiring Exit Point
6. Section Locks
7. Padded Handlebar
8. Wiring Entry Point
9. Sizing Insert



Connecting Your Microphone

- Remove Rubber Cap (1) and discard if so desired.
- Align microphone with Microphone Screw (2) and turn clockwise to tighten.
- If necessary, use included sizing nut to achieve a perfect fit.
- For additional stability and equipment safety, tighten Head Screw (4).

Working the Telescoping Sections

- Twist Section Locks (6) counterclockwise to loosen telescoping sections.
- Keep one hand on Padded Handlebar (7) and extend sections with other.
- Twist Section Locks (6) clockwise to tighten telescoping sections.

Wiring Your Boompole Internally

If you're a DIYer or a wiring professional, you'll appreciate the MPL-10's hollow core and wiring entry and exit points. This enables you to customize your microphone cable's length and fit, as well as hide it away within your new MPL-10.

- Locate Sizing Insert (9) at bottom of boompole.
- If necessary, turn insert counterclockwise to remove.
- Turn Removable Head (3) counterclockwise to remove.
- Push unfinished end of microphone cable into Wiring Entry Point (8), and proceed to pull it through Wiring Exit Point (5).
- Nestle wires in little cutout while reattaching Removable Head (3).
- Tighten Head Screw (4) by inserting a hex key and turning clockwise.

www.lyxpro.com

Distributed by C&A Marketing, Inc.
2 Bergen Turnpike, Ridgefield Park, NJ 07660
info@lyxpro.com

MADE IN CHINA

LyxPro is a trademark of C&A IP Holdings, LLC
©2014 All Rights Reserved