



# MPL-20 MICROPHONE BOOMPOLE WITH INTERNAL CABLE User Manual

LYXMPL20



## Introduction

Thank you for purchasing the LyxPro microphone boompole with internal cable. This User Guide is intended to provide you with guidelines to ensure that operation of this product is safe and does not pose risk to the user. Any use that does not conform to the guidelines described in this User Guide may void the limited warranty.

For the safe and correct use of this product, please read this guide before using the product and keep these instructions for reference.

## Features

- Lightweight, high-grade aluminum construction
- 5 locking sections for reach range of 2.4 ft. to 9.25 ft. (0.73 – 2.82m)
- Easy-twist section locks enable quick, one-hand adjustments
- Padded handle
- Internal cable


## Box Contents

Microphone boompole with internal cable

User guide

## Parts & Controls

1. Rubber Cap
2. Microphone Screw
3. Removable Head
4. Head Screw
5. Cable Exit Point
6. Section Locks
7. Padded Handle
8. Wiring Entry Point
9. Cable with XLR connection



## Connecting Your Microphone

- Remove rubber cap (1) and discard if desired.
- Align microphone with microphone screw (2) and turn clockwise to tighten.
- If necessary, use included sizing nut to achieve a perfect fit.
- For additional stability and equipment safety, tighten head screw (4).

## Adjusting the Length

- Twist section locks (6) counterclockwise to loosen sections.
- Keep one hand on handle (7) and extend sections with the other.
- Twist section locks (6) clockwise to tighten sections.

## Customer Service:

info@lyxpro.com  
866-849-3049

www.lyxpro.com

C&A Marketing, Inc.  
114 Tived Lane East  
Edison, NJ 08837 USA

C&A Marketing UK LTD  
167 Hermitage Road  
Crusader Industrial Estate  
London N4 1LZ  
United Kingdom

info@lyxpro.com

MADE IN CHINA

LyxPro is a trademark of  
C&A IP Holdings, LLC  
©2016 All Rights Reserved