VRI50 VOCAL BOOTH User Guide SKU: LYXVRI50



Hello!

Thank you for purchasing the LyxPro[®] Vocal Booth VRI-50. This User Guide is intended to provide you with guidelines to ensure that operation of this product is safe and does not pose risk to the user. Any use that does not conform to the guidelines described in this User Guide may void the limited warranty. Please read all directions before using the product and retain this guide for reference. This product is intended for household use only. It is not intended for commercial use.

This product is covered by a limited one-year warranty. Coverage is subject to limits and exclusions. See warranty for details.

CONTENTS:

SAFETY PRECAUTIONS	1
PACKAGE CONTENTS	2
PRODUCT OVERVIEW	2
ABOUT THE LYXPRO® VOCAL BOOTH VRI-50	2
	2
	3
	3
GET IN TOUCH!	4

Safety Precautions

1. WARNING: CHOKING HAZARD – Small parts. This product contains small parts and is not suitable for children under 3 years old.

2. Remove all packaging before using this device. Please keep all packaging materials out of reach of children and pets.

3. Properly dispose of all packing materials immediately after unpacking product, as the bags used for packaging could present a suffocation or choking hazard.

4. Read all instructions carefully before attempting to operate this device. Improper usage could result in injury or a reduction in efficacy.

Package Contents

- Microphone Shield
- Mounting Hardware Set
- User Guide

Product Overview

- 1. Stationary Panels (3)
- 2. Folding Panels (2)
- 3. Stability Feet (3)
- 4. Position Locks (2)
- 5. Stand Clamps (2)
- 6. Clamp Levers (2)



About The LyxPro[®] Vocal Booth VRI-50

This portable microphone shield allows you to reduce ambient noise to create a "dry" recording in any environment. The metal and foam panels are easy to position behind your microphone when recording vocals and other live audio.

Using This Vocal Booth

Initial Setup:

- 1. Unfold side Folding Panels (2) by turning Position Locks (4) and Stability Feet (3) counterclockwise.
- 2. Adjust panels to desired position, then tighten Position Locks (4) and Stability Feet
 (3) by turning back in a clockwise direction.
- 3. Set the Vocal Booth securely on a flat, stable surface.

Mounting on Microphone Stand:

- 1. Loosen Clamp Levers (6) by turning counterclockwise.
- 2. If necessary, you may use a hex key (not included) to loosen Stand Clamp (5) screws.
- 3. Slide the microphone stand through Stand Clamps (5).
- 4. Tighten Clamp Levers 6 by turning back in a clockwise direction.

Mounting a Microphone:

You will require the included Mounting Hardware Set for this operation. The set consists of:

A. Support Pole (A) B. Support Bar (B) C. Washers (2) (C)





To mount the microphone:

- 1. Remove middle Stability Foot 3 by turning counterclockwise.
- 2. Place threaded end of Stability Foot (3) through round hole in Support Bar (B).
- 3. Replace Stability Foot (3), which should now have Support Bar (B) in position.
- 4. Tighten Stability Foot (3) by turning back in a clockwise direction.
- 5. Unscrew knob on the bottom of Support Pole (B) by turning counterclockwise.
- 6. Remove one of the Washers (C), leave the other one on the Support Pole (B).
- 7. Place threaded end of Support Pole (B) through the long opening on the Support Bar (B).
- 8. Replace the washer you had removed in Step 6 and the bottom knob of Support Pole **B** by turning back in a clockwise direction, but DO NOT TIGHTEN.
- 9. Mount microphone to the top of the Support Bar (B), and then proceed to tighten the Support Pole in place.

Technical Specifications

- Dimensions: 16.9" x 15" x 12.8"
- Weight: 6.2 lbs.
- Mounting Hardware:
 - Max Length 5.9"
 - Motion Range 4.5"
 - Supporting Height 4.1"

Warranty Information

LIMITED WARRANTY ON LYXPRO[®] VOCAL BOOTH VRI-50

THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE. WE WARRANT THAT DURING THE WARRANTY PERIOD, THE PRODUCT WILL BE FREE FROM DEFECTS IN

WE WARRANT THAT DURING THE WARRANTY PERIOD, THE PRODUCT WILL BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP.

LIMITATION OF LIABILITY

TO THE EXTENT NOT PROHIBITED BY LAW, THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, ORAL, WRITTEN, STATUTORY, EXPRESS OR IMPLIED. EXCEPT FOR THE EXPRESS WARRANTIES CONTAINED IN THIS LIMITED WARRANTY STATEMENT AND TO THE EXTENT NOT PROHIBITED BY LAW, WE DISCLAIM ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME STATES DO NOT ALLOW DISCLAIMERS OF IMPLIED WARRANTIES, SO THIS DISCLAIMER MAY NOT APPLY TO YOU. TO THE EXTENT SUCH WARRANTIES CANNOT BE DISCLAIMED UNDER THE LAWS OF YOUR JURISDICTION, WE LIMIT THE DURATION AND REMEDIES OF SUCH WARRANTIES TO THE DURATION OF THIS EXPRESS LIMITED WARRANTY.

OUR RESPONSIBILITY FOR DEFECTIVE GOODS IS LIMITED TO REPAIR, REPLACEMENT OR REFUND AS DESCRIBED BELOW IN THIS WARRANTY STATEMENT.

WHO MAY USE THIS WARRANTY? C&A Marketing, Inc. located at 114 Tived Lane East, Edison, NJ (**"we"**) extend this limited warranty only to the consumer who originally purchased the product (**"you**"). It does not extend to any subsequent owner or other transferee of the product.

WHAT DOES THIS WARRANTY COVER? This limited warranty covers defects in materials and workmanship of the LyxPro[®] Vocal Booth VRI-50 (the "product") for the Warranty Period as defined below.

WHAT DOES THIS WARRANTY NOT COVER? This limited warranty does not cover any damage due to: (a) transportation; (b) storage; (c) improper use; (d) failure to follow the product instructions or to perform any preventive maintenance; (e) modifications; (f) unauthorized repair; (g) normal wear and tear; or (h) external causes such as accidents, abuse, or other actions or events beyond our reasonable control.

WHAT IS THE PERIOD OF COVERAGE? This limited warranty starts on the date of your purchase and lasts for one year (the "Warranty Period"). The Warranty Period is not extended if we repair or replace the product. We may change the availability of this limited warranty at our discretion, but any changes will not be retroactive.

WHAT ARE YOUR REMEDIES UNDER THIS WARRANTY? With respect to any defective product during the Warranty Period, we will, at our sole discretion, either: (a) repair or replace such product (or the defective part) free of charge or (b) refund the purchase price of such product if an exchange unit cannot be provided.

HOW DO YOU OBTAIN WARRANTY SERVICE? To obtain warranty service, you must contact us at 1-866-849-3049 or by email at info@lyxpro.com during the Warranty Period to obtain a Defective Merchandise Authorization ("**DMA**") number. No warranty service will be provided without a DMA number and return shipping costs to our facilities shall be assumed by you, the purchaser. Shipping costs of the replacement unit to you shall be assumed by us.

Get in Touch! info@lyxpro.com 1-866-849-3049 www.lyxpro.com Distributed by C&A Marketing, Inc. 114 Tived Lane East, Edison NJ 08837.

All other products, brand names, company names, and logos are trademarks of their respective owners,

used merely to identify their respective products, and are not meant to connote any sponsorship, endorsement or approval.

MADE IN CHINA

LyxPro is a trademark of C&A IP Holdings, LLC in the US, Canada, China and the EU ©2019. C&A IP Holdings, LLC. All Rights Reserved